



Accumulator and Dynamometer Experiment: EXP-02

Greg Flynn

This document contains information about how to set up an experiment to drive the dynamometer with the accumulator.

Table of Contents

Desired objectives	3
Required Hardware	3
Required Software	3
Hardware Setup	4
Single pack	Error! Bookmark not defined.
Full accumulator setup	4
Software Setup	5
Data.....	5
Desired data.....	5
AIRs tests	Error! Bookmark not defined.
Thévenin Voltage	Error! Bookmark not defined.
Temperature	5
Appendix A: Wiring requirements	6

Desired objectives

This experiment should verify the packs can drive the motor. This test is not for data acquisition but it could be modified easily to record information for physics calculations.

In this experiment the load is modified to enable to motor to operate at different torques.

To run these test a safety plan must have already been agreed and accepted by the ECE Director of Laboratories.

Required Hardware

- 4 Packs in series
- Motor load
- Basic GLV safety loop
- PPE per safety plan
- Danger zone per safety plan
- Cables as specified in Appendix A
- Temperature Probe
- Multimeter
- Current probe

Required Software

- TeamViewer

Hardware Setup

Full accumulator setup




Figure 1 Full 4 cell test

Software Setup

- Turn Test Stand PC on and log in
- Leave the Dyno Room and login into the remote PC.
- Launch Teamviewer and enter the following Partner ID: 554547715.
- Enter the password: AEC401
- Once launched open Oracle VM Virtual Box
- Select openSUSE and press Start
- Once open, Click on the Dyno Icon located on the desktop.
- Enter the password AEC401

Now the GUIs will be displayed and you will be able to control your test from there

Data

Perform full stress test. Ramp the RPM with a given fixed load. Do not adjust the load while the motor is spinning, this could cause RUD of the motor.

Desired data

It is desired to get:

- Torque
- Current
- Cell temperature

Current

Note if the current gets over 200A for a sustained amount of time. The fuses are rated at 200A

Temperature

While testing ensure that no part of the pack gets 40C above ambient temperature.

Witness/examiner signature

Date

Pass/Fail

Appendix A: Wiring requirements

Pin	Color	Label	Wiring Diagram	Notes
1	WHT	SL1		1 WHT SL1
2	BRN	SL2		2 BRN SL2
3	RED	AIRs+		3 RED AIRs+
4	BLK	AIRs-		4 BLK AIRs-
1	WHT	SL1		1 Jump pin
2	BRN	SL2		2 1 and 2
3	RED	AIRs+		3 Leave pin
4	BLK	AIRs-		4 3 and 4
1	RED	TSV HV		1 RED TSV HV
			Bare	
1	RED	TSV HV		1 RED TSV HV
			Bare	
1	RED	TSV HV		1 RED TSV HV
			Bare	
1	RED	TSV HV		1 RED TSV HV
			Bare	
1	RED	TSV HV		1 RED TSV HV
			Bare	

Cable	What packs use it	Total count for full test
W6	1,2,3,4	4
W7	1,2,3,4	1
W12	1	1
TW2	2,4	0
TW3	3	0
TW4	1,3	0
W13	2,4	1